DIAGNOSIS AND TESTING

Climate Control System

Refer to Wiring Diagrams Cell 54 for schematic and connector information.

Refer to Wiring Diagrams Cell 55 for schematic and connector information.

Special Tool(s)

ST2332-A	Worldwide Diagnostic System (WDS) 418-F224, New Generation STAR (NGS) Tester 418-F052, or equivalent scan tool
Г	Rotunda 73 III Automotive Meter 105-R0057 or equivalent
ST1928-A	R134a Manifold Gauge Set 176-R032A or equivalent
ST1176-A	Vacuum Pump Kit 416-D002 (D95L-7559-A) or equivalent
ST1501-A	Connector, Refrigerant Pressure Line 412-093 (T94P-19623-E)
Б. 100 ГА В. 00000 ST1252-А	Set, A/C Fittings 412-DS028 (014-00333, D93L-19703-B) or equivalent

(Continued)

Special Tool(s)

ST2351-A	Refrigerant Leak Detector 216-00001 or equivalent
68 ST1474-A	Pressure Test Kit 014-R1072 or equivalent
ST1391-A	Breakout Box, EEC V Control System 418-049 (014-00950, T94L-50-EEC-V)
ST1179-A	Starter, Alternator, Battery, Regulator Electrical Tester (S.A.B.R.E.) 010-00736 or equivalent

Manual Climate Control Vacuum Schematic



A0015389

Item	Part Number	Description
1		Panel airflow
2	_	Floor console door, full vacuum position (floor console equipped only)
3	18A318	Vacuum control motor—defrost door
4		Defrost door, full vacuum position
5	_	Defrost airflow

Item	Part Number	Description
6		Side window demister airflow
7		Supplemental temperature blend door, full heat position
8		Recirculation air inlet
9	18731	Supplemental recirculation air inlet door, full vacuum position
10	18731	Air inlet door, full vacuum position
(Continu	ed)	

Item	Part Number	Description				
11	_	Outside air inlet				
12	19N619	Pollen filter (optional)				
13	18A318	Vacuum control motor—air inlet doors				
14	_	Recirculation air inlet				
15	19805	Blower motor				
16	19860	Evaporator core				
17		Temperature blend door, full heat position				
18	18476	Heater core				
19	—	A/C evaporator case damper door, full heat position				
20		Panel/floor door, full vacuum position				
21	_	Floor airflow				
22	_	To vacuum distribution				
23	19A566	Vacuum reservoir tank				
24	19B888	Function selector switch				
25	18A318	Vacuum control motor—panel/floor door				
26	—	Floor console airflow (floor console equipped only)				
27	18A318	Vacuum control motor—floor console door (floor console equipped only)				

Manual Climate Control Vacuum Connector End View



Port Number	Line Color	Function
1	White	Air inlet door
2	Red	floor door
3	Black	Source vacuum
4	_	Not used
5	Blue	floor door
6	Yellow	Defrost door ^a

a Also controls the floor console door, if equipped.

MANUAL CLIMATE CONTROL VACUUM APPLICATION CHART

			Function Selector Switch Position							
Port Number	Line Color	Function	MAX A/C	A/C	PANEL	OFF	PNL/ FLR	FLR	FLR/ DEF	DEF
1	White	Outside/ recircu- lated air	V	NV	NV	V	NV	NV	NV	NV
2	Red	Full floor	NV	NV	NV	V	NV	V	NV	NV
3	Black	Source vacuum	V	V	V	V	V	V	V	
5	Blue	Panel/ floor	NV	NV	NV	V	V	V	V	NV
6	Yellow	Defrost ^a	V	V	V	NV	V	NV	NV	NV

a Also controls the floor console door, if equipped.

V = vacuum

NV = no vacuum

Electronic Automatic Temperature Control Vacuum Schematic



A0015390

Item	Part Number	Description
1		Panel airflow
2		Floor console door, full vacuum position (floor console equipped only)
3	18A318	Vacuum control motor—defrost door
4		Defrost door, full vacuum position
5		Defrost airflow

Item	Part Number	Description
6		Side window demister airflow
7		Supplemental temperature blend door, full heat position
8		Recirculation air inlet
9	18731	Supplemental recirculation air inlet door, full vacuum position
10	18731	Air inlet door, full vacuum position
(Continu	ed)	

Item	Part Number	Description				
11	—	Outside air inlet				
12	19N619	Pollen filter (optional)				
13	18A318	Vacuum control motor—air inlet doors				
14	_	Recirculation air inlet				
15	19805	Blower motor				
16	19860	Evaporator core				
17	_	Temperature blend door, full heat position				
18	18476	Heater core				
19		A/C evaporator case damper door, full heat position				
20		Panel/floor door, full vacuum position				
21	_	Floor airflow				
22	_	To vacuum distribution				
23	19A566	Vacuum reservoir tank				
24	18C612	Remote climate control (RCC) module				
25	18A318	Vacuum control motor—panel/floor door				
26	_	Floor console airflow (floor console equipped only)				
27	18A318	Vacuum control motor—floor console door (floor console equipped only)				

Electronic Automatic Temperature Control Vacuum Connector End View



Port Number	Line Color	Function
1		Not used
2	Yellow	Defrost door ^a
3	Blue	Panel/floor door
4	Black	Source vacuum
5	White	Air inlet door
6	Red	Panel/floor door

a Also controls the floor console door, if equipped.

ELECTRONIC AUTOMATIC TEMPERATURE CONTROL MANUAL OVERRIDE VACUUM APPLICATION CHART

			Manual Override Selector Button						
Port Number	Line Color	Function	MAX A/C	PANEL	OFF	PNL/ FLR	FLR	FLR/ DEF	DEF
2	Yellow	Defrost ^a	V	V	NV	V	NV	NV	NV
3	Blue	Panel/ floor	NV	NV	V	V	V	V	NV
4	Black	Source vacuum	V	V	V	V	V	V	V
5	White	Outside/ recirculated air	V	NV	V	NV	NV	NV	NV
6	Red	Full floor	NV	NV	V	NV	V	NV	NV

a Also controls the floor console door, if equipped.

V = vacuum

NV = no vacuum

Inspection and Verification

- 1. Verify the customer's concern by operating the climate control system to duplicate the condition.
- 2. Inspect to determine if one of the following mechanical or electrical concerns apply:

Visual Inspection Chart

Mechanical	Electrical
 Loose, missing or damaged A/C compressor drive belt Loose or disconnected A/C clutch Loose, misrouted or damaged vacuum lines ^a Broken or leaking vacuum control motor^a Discharged A/C system Broken or leaking refrigerant lines 	 Open fuses Blower motor inoperative A/C compressor inoperative Circuitry open/shorted Disconnected, loose fitting, or incorrectly installed electrical connectors and pins

- a A leak in the vacuum control circuit may occur during acceleration (slow leak), may exist at all times (large leak), and may exist only when specific functions are selected (indicating a leak in that portion of the circuit). The vacuum hoses used in the passenger compartment control circuit are constructed from PVC plastic material. The vacuum hoses used in the engine compartment are constructed of Hytrel[®]. Because of the materials used, never pinch the vacuum hoses off during diagnosis to locate a leak. A wood golf tee can be used as a plug when it is necessary to plug one end of the vacuum hose for leak test purposes.
- 3. As pinpoint tests and measurements are being carried out, be sure to inspect for any disconnected, loose fitting, or incorrectly installed component, module and in-line electrical connectors and pins.
- 4. If the inspection reveals obvious concern(s) that can be readily identified, repair as required.
- 5. If the concern remains after the inspection, connect the scan tool to the data link connector (DLC) located beneath the instrument panel and select the vehicle to be tested from the scan tool menu. If the vehicle selection cannot be entered:
 - check that the program card is correctly installed.
 - check the connections to the vehicle.
 - check the ignition switch position.

If the scan tool still does not allow with the vehicle selection to be entered, refer to the scan tool manual.

- 6. Carry out the DATA LINK DIAGNOSTIC TEST using the scan tool. If the scan tool responds with:
 - CKT 914 and CKT 915 = ALL MODULE NO RESPONSE/NOT EQUIPPED, go to Section 418-00 to diagnose the communications network concern.
 - If the powertrain control module (PCM) (12A650) is not listed for a communication concern, turn the A/C controls to OFF and carry out the self-test diagnostics for the PCM.
 - If the remote climate control (RCC) module (18C612) is not listed for a communication concern on vehicles equipped with EATC, carry out the Remote Climate Control Module Self-Test.
- If any PCM or RCC module diagnostic trouble codes (DTCs) are retrieved and related to the concern, go to the POWERTRAIN CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX or the REMOTE CLIMATE CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX to continue diagnostics.
- 8. If no DTCs related to the concern are retrieved, go to the SYMPTOM CHART to continue the diagnostics.
- 9. If the RCC module cannot be accessed by the scan tool, go to Pinpoint Test I.

Remote Climate Control Module Self-Test

- The remote climate control (RCC) module self-test will not detect concerns associated with data link messages like engine coolant temperature or vehicle speed signals. A scan tool must be used to retrieve these concerns.
- The RCC module self-test will detect concerns in the system control functions and will display hard diagnostic trouble codes (DTCs) in addition to intermittent diagnostic trouble codes for concerns that occur during system operation. The vehicle interior temperature should be between 4°-38°C (40°-100°F) when carrying out the self-test. If the temperature is not within the specified range, false in-car temperature sensor DTCs will be displayed.
- The self-test can be initiated at any time. Normal operation of the system stops when the self-test is activated.

• To enter the self-test, press the OFF and floor buttons simultaneously and then press the AUTO button within two seconds. The display will show a dashed line in the center of the climate control display window of the integrated control panel (ICP).



• The test may run as long as 30 seconds. Record all DTCs displayed. The self-test is completed when 888 appears in the center of the climate control display window of the ICP.



- If any DTCs appear during the self-test, refer to the REMOTE CLIMATE CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX. Carry out the diagnostic procedure given under ACTION TO TAKE for each DTC given.
- If a condition exists but no DTCs appear during the self-test, refer to the SYMPTOM CHART condition: The EATC System Is Inoperative, Intermittent or Incorrect Operation.
- To exit the self-test and retain all intermittent DTCs, press the "—" (cooler) side of the TEMP button. The RCC module will exit the self-test and retain all intermittent DTCs.



• To exit the self-test and clear all DTCs, press the front defrost button. All RCC module DTCs will be cleared.



- Always exit the self-test before powering the system down (system turned off).
- Intermittent DTCs will be deleted after 80 ignition switch ON cycles after the intermittent condition occurs.

Diagnostic Trouble Code (DTC) Indexes

DTC	Description	Action
P1436	A/C Evaporator Air Temperature Sensor Circuit Low	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
P1437	A/C Evaporator Air Temperature Sensor Circuit High	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.

POWERTRAIN CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX

POWERTRAIN CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX (Continued)

DTC	Description	Action
P1460	Wide Open Throttle A/C Primary Circuit Malfunction	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.

POWERTRAIN CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX (Continued)

DTC	Description	Action
P1464	A/C Demand Out Of Self-Test Range	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
P1469	Low A/C Cycling Period	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.

REMOTE CLIMATE CONTROL MODULE DIAGNOSTIC TROUBLE CODE (DTC) INDEX

	RCC Mo	dule DTC		
PCM DTC	Self-test (hard) faults	Run-time (intermi- ttent) faults	Description	Action to Take
B1249	024	025	Temperature Blend Door Failure or Short	GO to Pinpoint Test A.
B1251	031	033	In-Vehicle Temperature Sensor Open	GO to Pinpoint Test B.
B1253	030	032	In-Vehicle Temperature Sensor Short to Ground	GO to Pinpoint Test B.
B1255	041	043	Ambient Temperature Sensor Open	GO to Pinpoint Test C.
B1257	040	042	Ambient Temperature Sensor Short to Ground	GO to Pinpoint Test C.
B1260	051	053	Solar Radiation Sensor Open	GO to Pinpoint Test D.
B1261	50	52	Solar Radiation Sensor Short to Ground	GO to Pinpoint Test D.
U1073	N/A	115	SCP Invalid Engine Coolant Signal	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
U1341	N/A	125	SCP Invalid Vehicle Speed Signal	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
U2005	N/A	195	ACP Communication Error Between Integrated Control Panel and Remote Climate Control Module	GO to Pinpoint Test E.

A/C Performance Check

- 1. Place the vehicle in the shade with the hood OPEN and windows DOWN in an enclosed shop area to minimize wind gust and sun load effects. Make sure the right front footwell is free of obstruction.
- 2. If equipped with manual climate control, with the engine running at idle, select MAX A/C (RECIRC) and set the temperature control to full COOL with the blower speed set to MEDIUM (Position 2).

- 3. If equipped with EATC, with the engine running at idle, select A/C and RECIRC and set the temperature to the lowest setting (60°F) with the blower manually set to MEDIUM blower speed (4 bars displayed).
- 4. Measure the ambient temperature and humidity adjacent to the passenger side mirror, at approximately evaporator core height.
- 5. With all vents opened, place a thermometer in the left center register and allow the temperature to stabilize for 6 to 8 minutes.
- 6. Record 5 vent temperature readings at the center register within 5 minutes.
- 7. Calculate the Average Center Vent Temperature.

A/C Performance Chart

1 Add the 5 recorded vent temperature readings to obtain the sum.

- 2 Divide the sum of the vent temperature readings by 5 to obtain the Average Center Vent Temperature.
- 8. Compare the Average Center Vent Temperature to the A/C performance chart for the ambient conditions at the time of testing.
 - If the Average Center Vent Temperature is less than the temperature in the A/C performance chart, no further diagnosis is required.
 - If the Average Center Vent Temperature is greater than the temperature in the A/C performance chart, refer to the Symptom Chart.

		Temperature (°F)							
Humidity(%)	68-72	73-77	78-82	83-87	88-92	93-97	98-102	103-107	108-112
5-14	_					< 44	< 45	< 45	< 45
15-24	_		< 44	< 45	< 45	< 46	< 47	< 48	< 48
25-34	< 43	< 44	< 45	< 46	< 47	< 48	< 49	< 50	< 52
35-44	< 43	< 45	< 46	< 48	< 49	< 50	< 52	< 53	< 55
45-54	< 44	< 46	< 47	< 49	< 51	< 53	< 54	< 56	_
55-64	< 44	< 46	< 48	< 51	< 51	< 55	< 57	< 59	_
65-74	< 45	< 47	< 50	< 52	< 54	< 57	—	_	_
75-84	< 45	< 48	< 51	< 53	< 56	< 59			
85-94	< 46	< 49	< 52	< 55		_		_	_

Symptom Chart

SYMPTOM CHART

	Condition	Possible Sources	Action
•	No communication with the remote climate control module—EATC	 Circuit open/short. Remote climate control module communication network. 	• GO to Pinpoint Test F.
•	The EATC system is inoperative, intermittent or incorrect operation	 Circuit open/short. Input sensor(s)/erratic input signals. Charging system. In-car temperature sensor hose and elbow. 	• GO to Pinpoint Test G.

SYMPTOM CHART (Continued)

Condition	Possible Sources	Action
Incorrect/erratic direction of airflow from the outlets—manual climate control	 No vacuum to the function selector switch. Function selector switch leaks vacuum. Air distribution door binding/stuck. Vacuum line kinked/pinched. Vacuum control motor. A/C vacuum check valve (19A563). A/C vacuum reservoir tank (19A566). Vacuum control motor actuator arm not connected to the door lever. 	• GO to Pinpoint Test H.
Incorrect/erratic direction of airflow from the outlets—EATC	 No vacuum to the remote climate control module. Remote climate control module leaks vacuum. Air distribution door binding/stuck. Vacuum line kinked/pinched. Vacuum control motor. A/C vacuum check valve (19A563). A/C vacuum reservoir tank (19A566). Vacuum control motor actuator arm not connected to the door lever. 	• GO to Pinpoint Test I.
• Insufficient, erratic, or no heat—manual climate control and EATC	 Low engine coolant level. Engine overheating. Plugged or partially plugged heater core. Temperature blend door binding/stuck. Temperature blend door actuator (19E616). Temperature blend door circuit open/shorted. 	• GO to Pinpoint Test J.
The A/C does not operate/does not operate correctly	 Open fuse. A/C control relay. Circuit open/short. A/C cycling switch (19E561). A/C system discharged/low charge. Pressure cutoff switch (19D594). A/C control. 	• GO to Pinpoint Test K.
• The A/C is always on	Circuit short.A/C control.A/C control relay.	• GO to Pinpoint Test L.

SYMPTOM CHART (Continued)

Condition	Possible Sources	Action
No operation in all the temperature settings—manu climate control	 Open fuse. Circuit open/short. Temperature control switch (19C733). Temperature blend door actuator (19E616). Temperature blend door binding/stuck. 	• GO to Pinpoint Test M.
The blower motor does not operate—manual climate control	 Open fuse. Circuit open/short. Blower motor (19805). Function selector switch (19B888). Blower motor relay (14B192). 	• GO to Pinpoint Test N.
• The blower motor is inoperative—EATC	 Open fuse. Circuit open/short. Blower motor. Blower motor speed control (19E624). Blower motor relay. Remote climate control module. 	• GO to Pinpoint Test O.
The blower motor does not operate correctly—manual climate control	 Circuit open/short. Blower motor. Blower motor switch (18578). Blower motor resistor (19A706). 	• GO to Pinpoint Test P.
• The blower motor operates continuously in high speed—manual climate control	Circuit short.Blower motor resistor.Blower motor switch.	• GO to Pinpoint Test Q.
• The blower motor operates continuously in high speed—EATC	 Circuit open/short. Blower motor speed control. Remote climate control module. 	• GO to Pinpoint Test R.
• No operation in high blows setting—manual climate control	erCircuit open.Blower motor switch.Blower motor.	• GO to Pinpoint Test S.
• No operation in lower speeds—manual climate control	Circuit open.Blower motor resistor.	• GO to Pinpoint Test T.
No operation in some blow settings—EATC	 Blower motor speed control. Remote climate control module. 	• GO to Pinpoint Test U.
The temperature set point does not repeat after turnin the ignition switch off—EATC	 Open fuse. Circuit open. Remote climate control module. 	• REPAIR circuit 385 (WH/RD) or circuit 729 (RD/WH) for an open. If okay, INSTALL a new remote climate control module.

SYMPTOM CHART (Continued)

	Condition		Possible Sources		Action
•	The temperature display will not switch between Celsius and Fahrenheit—EATC	•	Integrated control panel (ICP) (18C864). Remote climate control module.	•	VERIFY correct front defrost and MAX A/C operation. If operation is correct, INSTALL a new remote climate control module. If operation is not correct, INSTALL a new ICP.

Pinpoint Tests

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT

	Test Step	Result / Action to Take
A1	CHECK THE BLEND DOOR ACTUATOR CLOCKWISE OPERATION	
	 Disconnect: Remote Climate Control Module C228. Key in ON position. Connect a fused jumper wire between RCC module C228 pin 21, circuit 249 (DB/LG) and RCC module C228 pin 11, circuit 729 (RD/WH). Connect a second fused jumper wire between RCC module C228 pin 22, circuit 250 (OG) and RCC module C228 pin 8, circuit 570 (BK/YE). 	
	A0013623	Yes GO to A2. No GO to A3.
L		(Continued)

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A2	CHECK THE BLEND DOOR ACTUATOR COUNTERCLOCKWISE	
	 Connect a fused jumper wire between RCC module C228 pin 22, circuit 250 (OG) and RCC module C228 pin 11, circuit 729 (RD/WH). Connect a second fused jumper wire between RCC module C228 pin 21, circuit 249 (DB/LG) and RCC module C228 pin 8, circuit 570 (BK/YE). 	
	A0013622	Yes GO to A9.
	 Does the air bypass door actuator motor move in the closed direction? 	No GO to A3.
A3	CHECK THE ACTUATOR CLOCKWISE OPERATION	
	 Remove the door actuator and disengage the actuator drive shaft from the actuator door. Refer to Section 412-04. Connect a fused jumper wire between RCC module C228 pin 21, circuit 249 (DB/LG) and RCC module C228 pin 11, circuit 729 (RD/WH). Connect a second fused jumper wire between RCC module C228 pin 22, circuit 250 (OG) and RCC module C228 pin 8, circuit 570 (BK/YE). 	
		Yes
	A0013623	INSPECT for binding or broken door or linkage. If no condition is found, INSTALL a new door actuator. REFER to Section 412-04. TEST the system for normal operation.
	Does the actuator motor move in the clockwise direction?	No GO to A4.

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A 4	CHECK THE ACTUATOR COUNTERCLOCKWISE OPERATION	
	 Connect a fused jumper wire between RCC module C228 pin 22, circuit 250 (OG) and RCC module C228 pin 11, circuit 729 (RD/WH). Connect a second fused jumper wire between RCC module C228 pin 21, circuit 249 (DB/LG) and RCC module C228 pin 8, circuit 570 (BK/YE). 	
	Α0013622	Yes INSPECT for binding, broken door or linkage. If no condition is found, INSTALL a new door actuator. REFER to Section 412-04. TEST the system for normal operation.
	 Does the air bypass door actuator motor move in the closed direction? 	No GO to A5.
A5	CHECK CIRCUITS 249 (DB/LG) AND 250 (OG) FOR A SHORT TO GROUND	
	 Disconnect: Temperature Blend Door Actuator C289. Measure the resistance between RCC module C228 pin 21, circuit 249 (DB/LG) and ground. Measure the resistance between RCC module C228 pin 22, circuit 250 (OG) and ground. 	
	A0042620 • Are the resistances greater than 10,000 ohms?	Yes GO to A6. No REPAIR the affected circuit for a short to ground. TEST the system for normal operation.
A6	CHECK CIRCUIT 249 (DB/LG) AND 250 (OG) FOR A SHORT TO POWER	
	Key in ON position.	1

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A6	CHECK CIRCUIT 249 (DB/LG) AND 250 (OG) FOR A SHORT TO POWER (Continued)	
	 Measure the voltage between RCC module C228 pin 21, circuit 249 (DB/LG) and ground. Measure the voltage between RCC module C228 pin 22, circuit 250 (OG) and ground. 	
		Yes REPAIR the affected circuit for a short to power. TEST the system for normal operation.
	Is voltage present?	No GO to A7
A7	CHECK CIRCUITS 249 (DB/LG) AND 250 (OG) FOR AN OPEN	
	 Key in OFF position. Measure the resistance between RCC module C228 pin 21, circuit 249 (DB/LG) and the temperature blend door actuator C289 pin 7, circuit 249 (DB/LG). Measure the resistance between RCC module C228 pin 22, circuit 250 (OG) and the temperature blend door actuator C289 pin 8, circuit 250 (OG). 	
		Yes
	A0042622	No REPAID the offected circuit for on onen
	Are the resistances less than 5 ohms?	TEST the system for normal operation.
		(Continued)

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

A8 CHECK CIRCUIT 250 (OG) AND 249 (DB/LG) FOR A SHORT Yes Curcuit 250 (OG) and RCC module C228 pin 21, circuit 249 (DB/LG). Image: Comparison of the state of the	Test Step	Result / Action to Take
 Measure the resistance between RCC module C228 pin 22, circuit 230 (OG) and RCC module C228 pin 21, circuit 249 (DB/LG). Yes INSTALL a new door actuator. REFER to Section 412-04. TEST the system for normal operation. No Resistance less than 5 ohms? A9 CHECK THE FEEDBACK POTENTIOMETER TOTAL RESISTANCE Key in OFF position. Measure the resistance between RCC module C228 pin 5. circuit 436 (RD/LG) and RCC module C228 pin 5. circuit 436 (RD/WH). Yes GO to A12. No Resistance between RCC module C228 pin 5. circuit 436 (RD/WH). Yes GO to A12. No Resistance between RCC module C228 pin 5. circuit 436 (RD/LG) and RCC module C228 pin 5. circuit 436 (RD/LG) and RCC module C228 pin 5. circuit 436 (RD/WH). Yes GO to A12. No If the resistance is greater than 6,000 ohms, GO to A10. If the resistance is less than 5,000 ohms, GO to A11. 	A8 CHECK CIRCUIT 250 (OG) AND 249 (DB/LG) FOR A SHORT TOGETHER	
Yes No A0042623 • Is the resistance less than 5 ohms? A0042623 • Is the resistance less than 5 ohms? A9 CHECK THE FEEDBACK POTENTIOMETER TOTAL RESISTANCE • Key in OFF position. • Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 5, circuit 438 (RD/WH). • Measure the resistance between RCC module C228 pin 5, circuit 438 (RD/WH). • Measure the resistance between RCC module C228 pin 5, circuit 438 (RD/WH). • He resistance is greater than 6,000 ohms, GO to A10. If the resistance is greater than 6,000 ohms, GO to A10. If the resistance is less than 5,000 ohms, GO to A11.	 Measure the resistance between RCC module C228 pin 22, circuit 250 (OG) and RCC module C228 pin 21, circuit 249 (DB/LG). 	
A0042623 Yes A0042623 INSTALL a new door actuator. REFER to Section 412-04. TEST the system for normal operation. No REPAIR circuit 250 (OG) and circuit 249 (DB/LG) for a short together. TEST the system for normal operation. No RESISTANCE • Key in OFF position. • Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Image: the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Image: the resistance between RCC module C228 pin 5, circuit 438 (RD/WH). Image: the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Image: the resistance between SCOM and 6,000 ohms? Yes GO to A12. No If the resistance is greater than 6,000 ohms, GO to A10. If the resistance is less than 5,000 ohms, GO to A11.		
 Is the resistance less than 5 ohms? Is the resistance less than 5 ohms? CHECK THE FEEDBACK POTENTIOMETER TOTAL RESISTANCE Key in OFF position. Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Is the resistance between 5,000 and 6,000 ohms? 		Yes INSTALL a new door actuator. REFER to Section 412-04. TEST the system for normal operation. No
 A9 CHECK THE FEEDBACK POTENTIOMETER TOTAL RESISTANCE Key in OFF position. Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Q (+ (- (+ (- (+ (+ (Is the resistance less than 5 ohms? 	(DB/LG) for a short together. TEST the system for normal operation.
 Key in OFF position. Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). Is the resistance between 5,000 and 6,000 ohms? 	A9 CHECK THE FEEDBACK POTENTIOMETER TOTAL BESISTANCE	
Yes GO to A12. NO If the resistance is greater than 6,000 ohms, GO to A10. If the resistance is less than 5,000 ohms, GO to A11.	 Key in OFF position. Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). 	
 Yes GO to A12. No If the resistance is greater than 6,000 ohms, GO to A10. Is the resistance between 5,000 and 6,000 ohms? 		
 Yes GO to A12. No If the resistance is greater than 6,000 ohms, GO to A10. Is the resistance between 5,000 and 6,000 ohms? GO to A11. 		
 A0015887 Is the resistance between 5,000 and 6,000 ohms? If the resistance is greater than 6,000 ohms, GO to A10. If the resistance is less than 5,000 ohms, GO to A11. 		Yes GO to A12.
• Is the resistance between 5,000 and 6,000 ohms?	A0015887	If the resistance is greater than 6,000 ohms, GO to A10.
	Is the resistance between 5,000 and 6,000 ohms?	If the resistance is less than 5,000 ohms, GO to A11.
A10 CHECK CIRCUITS 436 (RD/LG) AND 438 (RD/WH) FOR AN OPEN	A10 CHECK CIRCUITS 436 (RD/LG) AND 438 (RD/WH) FOR AN OPEN	
Disconnect: Temperature Blend Door Actuator C289.	Disconnect: Temperature Blend Door Actuator C289.	1

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

Test Step	Result / Action to Take
A10 CHECK CIRCUITS 436 (RD/LG) AND 438 (RD/WH) FOR AN OPEN (Continued)	
 Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and the temperature blend door actuator C289 pin 6, circuit 436 (RD/LG). Measure the resistance between RCC module C228 pin 20, circuit 438 (RD/WH) and the temperature blend door actuator C289 pin 5, circuit 438 (RD/WH). 	
	Yes INSTALL a new temperature blend door actuator. REFER to Section 412-04. TEST the system for normal operation.
A0042624 Are the resistances less than 5 ohms?	No REPAIR the affected circuit for an open. TEST the system for normal operation.
A11 CHECK CIRCUIT 438 (RD/WH) FOR A SHORT TO CIRCUIT 436 (RD/LG)	
 Disconnect: Temperature Blend Door Actuator C289. Measure the resistance between RCC module C228 pin 20, circuit 438 (RD/WH) and RCC module C228 pin 5, circuit 436 (RD/LG). 	
	Yes INSTALL a new temperature blend door actuator (19E616). REFER to Section 412-04. TEST the system for normal operation.
A0015887 Is the resistance greater than 10.000 ohms?	REPAIR circuits 438 (RD/WH) for a short to circuit 436 (RD/LG). TEST the system for normal operation.
A12 CHECK POTENTIOMETER LOW SIDE RESISTANCE	
Drive the actuator to the full clockwise position. Refer to A1.	1

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A12	CHECK POTENTIOMETER LOW SIDE RESISTANCE (Continued)	
	 Measure the resistance between RCC module C228 pin 9, circuit 437 (YE/LG) and RCC module C228 pin 20, circuit 438 (RD/WH). 	
		Yes
	A0013634	No If the resistance is greater than 3,000 ohms, GO to A13.
	 Is the resistance between 250 and 3,000 ohms? 	If the resistance is less than 250 ohms, GO to A14.
A13	CHECK CIRCUIT 437 (YE/LG) FOR AN OPEN	
	 Disconnect: Temperature Blend Door Actuator C289. Measure the resistance between RCC module C228 pin 9, circuit 437 (YE/LG) and the temperature blend door actuator C289 pin 1, circuit 437 (YE/LG). 	
		Yes INSTALL a new temperature blend door actuator (19E616). REFER to Section 412-04. TEST the system for normal operation.
	A0013632	No REPAIR circuit 437 (YE/LG) for an open.
A14	CHECK CIRCUIT 438 (RD/WH) AND CIRCUIT 437 (YE/LG) FOR	TEST the system for normal operation.
	A STURI IUGEINER	4
	Disconnect. Temperature Dienu Dour Actuator 0203.	

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A14	CHECK CIRCUIT 438 (RD/WH) AND CIRCUIT 437 (YE/LG) FOR A SHORT TOGETHER (Continued)	
	 Measure the resistance between RCC module C228 pin 20, circuit 438 (RD/WH) and RCC module C228 pin 9, circuit 437 (YE/LG). 	
	A0013634	Yes INSTALL a new temperature blend door actuator (19E616). REFER to Section 412-04. TEST the system for normal operation. No REPAIR circuits 438 (RD/WH) and circuit 437 (YE/LG) for a short together. TEST
A 4 F	Is the resistance greater than 10,000 ohms?	the system for normal operation.
AIS	 Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 9, circuit 437 (YE/LG). 	
	A0013634	Yes GO to A17. No If the resistance is greater than 6,000 ohms, INSTALL a new temperature blend door actuator. REFER to Section 412-04. TEST the system for normal operation.
	Is the resistance between 3,000 and 6,000 ohms?	If the resistance is less than 3,000 ohms, GO to A16.
A16	CHECK CIRCUIT 437 (YE/LG) FOR A SHORT TO CIRCUIT 436 (RD/LG)	
	Disconnect: Temperature Blend Door Actuator C289.	1
L	·	(Continued)

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A16	CHECK CIRCUIT 437 (YE/LG) FOR A SHORT TO CIRCUIT 436 (RD/LG) (Continued)	
	 Measure the resistance between RCC module C228 pin 5, circuit 436 (RD/LG) and RCC module C228 pin 9, circuit 437 (YE/LG). 	
		Yes INSTALL a new temperature blend door actuator (19E616). REFER to Section 412-04. TEST the system for normal operation. No REPAIR circuits 437 (YE/LG) for a short to circuit 436 (BD/LG) TEST the system for
	Is the resistance greater than 10,000 ohms?	normal operation.
A17	 CHECK CIRCUITS 436 (RD/LG) AND 437 (YE/LG) FOR A SHORT TO GROUND Disconnect: Temperature Blend Door Actuator C289. Measure the resistance between RCC module C228 pin 5, 	-
	circuit 436 (RD/LG) and ground. Measure the resistance between RCC module C228 pin 9, circuit 437 (YE/LG) and ground.	
		Yes
	A0042625	No REPAIR the affected circuit for a short to ground. TEST the system for normal
	Are the resistances greater than 10,000 ohms?	operation.
A18	CHECK CIRCUITS 436 (RD/LG), 437 (YE/LG) AND 438 (RD/WH) FOR A SHORT TO POWER	
	Key in ON position.	
		(Continued)

PINPOINT TEST A: DTC B1249 — BLEND DOOR FAILURE OR SHORT (Continued)

	Test Step	Result / Action to Take
A18	CHECK CIRCUITS 436 (RD/LG), 437 (YE/LG) AND 438 (RD/WH) FOR A SHORT TO POWER (Continued)	
	 Measure the voltage between RCC module C228 pin 5, circuit 436 (RD/LG), RCC module C228 pin 9, circuit 437 (YE/LG) and RCC module C228 pin 20, circuit 438 (RD/WH) and ground. 	
		Yes REPAIR the affected circuit for a short to power. TEST the system for normal operation.
	A0042626 =	No INSPECT for a broken door or linkage. If no condition is found, INSTALL a new RCC module. REFER to Section 412-04. TEST the system for normal operation.

PINPOINT TEST B: DTC B1251 OR DTC1253 — A/C IN-VEHICLE TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND

	Test Step	Result / Action to Take
B1	CHECK THE SENSOR RESISTANCE	
	 Key in OFF position. Disconnect: In-Vehicle Temperature Sensor C233. Measure the resistance between the in-vehicle temperature sensor terminals. 	
	A0013635	Yes GO to B2.
	 Is the resistance within the specified values for these temperature ranges: 10-20°C (50-68°F), 37,000-58,000 ohms; 20-30°C (68-86°F), 24,000-37,000 ohms; 30-40°C (86-104°F), 16,000-24,000 ohms? 	No INSTALL a new in-vehicle temperature sensor. TEST the system for normal operation.
B2	CHECK THE REMOTE CLIMATE CONTROL (RCC) MODULE OUTPUT VOLTAGE	
	Key in ON position.Press the AUTOMATIC button.	

PINPOINT TEST B: DTC B1251 OR DTC1253 — A/C IN-VEHICLE TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)

	Test Step	Result / Action to Take
B2	CHECK THE REMOTE CLIMATE CONTROL (RCC) MODULE OUTPUT VOLTAGE (Continued)	
	 Measure the voltage between the in-vehicle temperature sensor C233, circuit 790 (WH/OG) and circuit 470 (PK/BK). 	
		Yes INSTALL a new RCC module. TEST the system for normal operation.
	A0040087	No If diagnosing DTC B1251, GO to B3.
	Is the voltage between 4.7 and 5.1 volts?	If diagnosing DTC B1253, GO to B5.
	 Key in OFF position. Disconnect: RCC Module C228. Measure the resistance between the RCC module C228 pin 23, circuit 790 (WH/OG) and the in-vehicle temperature sensor C233, circuit 790 (WH/OG). 	
		Yes GO to B4.
	AUU13037	NO REPAIR circuit 790 (WH/OG) for an open
	Is the resistance less than 5 ohms?	TEST the system for normal operation.
B4	CHECK CIRCUIT 470 (PK/BK) FOR AN OPEN	
	NOTE: When carrying out tests, allow time for resistance measurement to stabilize.	
L		

PINPOINT TEST B: DTC B1251 OR DTC1253 — A/C IN-VEHICLE TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)



PINPOINT TEST C: DTC B1255 OR DTC B1257 — AMBIENT TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND

	Test Step	Result / Action to Take
C1	CHECK THE AMBIENT TEMPERATURE SENSOR RESISTANCE	
	 Key in OFF position. Disconnect: Ambient Temperature Sensor C198. Measure the resistance between the ambient temperature sensor terminals. 	
	A0013640	Yes GO to C2.
	 Is the resistance within the specified values for these temperature ranges: 10-20°C (50-68°F), 37,000-58,000 ohms; 20-30°C (68-86°F), 24,000-37,000 ohms; 30-40°C (86-104°F), 16,000-24,000 ohms? 	No INSTALL a new ambient air temperature sensor and bracket. TEST the system for normal operation.
C2	CHECK THE REMOTE CLIMATE CONTROL MODULE OUTPUT VOLTAGE	
	 Key in ON position. Press the AUTOMATIC button. Measure the voltage between the ambient temperature sensor C198, circuit 788 (RD/OG) and circuit 470 (PK/BK). 	
		Vec
		INSTALL a new RCC module. TEST the system for normal operation.
	A0013641	If diagnosing DTC 1255, GO to C3.
	Is the voltage between 4.7 and 5.1 volts?	If diagnosing DTC 1257, GO to C5.
C3	CHECK CIRCUIT 788 (RD/OG) FOR AN OPEN	
	Key in OFF position.Disconnect: RCC Module C228.	

PINPOINT TEST C: DTC B1255 OR DTC B1257 — AMBIENT TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)

Test Step	Result / Action to Take
C3 CHECK CIRCUIT 788 (RD/OG) FOR AN OPEN (Continued)	
 Measure the resistance between the RCC module C228 pin 7, circuit 788 (RD/OG) and the ambient temperature sensor C198, circuit 788 (RD/OG). 	
A0013642 • Is the resistance less than 5 ohms?	Yes GO to C4. No REPAIR circuit 788 (RD/OG) for an open. TEST the system for normal operation.
C4 CHECK CIRCUIT 470 (PK/BK) FOR AN OPEN	
Measure the resistance between the RCC module C228 pin 15, circuit 470 (PK/BK) and the ambient temperature sensor C198, circuit 470 (PK/BK).	
	Yes INSTALL a new RCC module. TEST the system for normal operation.
	REPAIR circuit 470 (PK/BK) for an open.
Is the resistance less than 5 ohms?	TEST the system for normal operation.
C5 CHECK CIRCUIT 788 (RD/OG) FOR A SHORT TO CIRCUIT 470 (PK/BK)	
Key in OFF position.Disconnect: RCC Module C228.	

PINPOINT TEST C: DTC B1255 OR DTC B1257 — AMBIENT TEMPERATURE SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)

	Test Step	Result / Action to Take
C5	CHECK CIRCUIT 788 (RD/OG) FOR A SHORT TO CIRCUIT 470 (PK/BK) (Continued)	
	 Measure the resistance between the ambient temperature sensor C198, circuit 788 (RD/OG) and circuit 470 (PK/BK). 	
		Yes
	A0038068	No REPAIR circuit 788 (RD/OG) for a short to circuit 470 (PK/BK). TEST the system for
	Is the resistance greater than 10,000 ohms?	normal operation.
C6	CHECK CIRCUIT 788 (RD/OG) FOR A SHORT TO GROUND	
	 Key in OFF position. Measure the resistance between the RCC module C228 pin 7, circuit 788 (RD/OG) and ground. 	
		Yes INSTALL a new RCC module. TEST the system for normal operation.
	A0040094 Is the resistance greater than 10.000 ohms?	No REPAIR circuit 788 (RD/OG) for a short to ground. TEST the system for normal operation.
L		

PINPOINT TEST D: DTC B1260 OR DTC B1261 — SOLAR RADIATION SENSOR OPEN CIRCUIT OR SHORT TO GROUND

	Test Step	Result / Action to Take
D1	CHECK THE SOLAR RADIATION SENSOR RESISTANCE	
	Key in OFF position.Disconnect: Solar Radiation Sensor C287.	

PINPOINT TEST D: DTC B1260 OR DTC B1261 — SOLAR RADIATION SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)

	Test Sten	Besult / Action to Take
D1		
	(Continued)	
	• Measure the resistance between the solar radiation sensor pin 1 and pin 5, component side.	
	A0015934 • Is continuity present and the resistance greater than 0 ohms?	Yes GO to D2 . No INSTALL a new solar radiation sensor and bracket. TEST the system for normal operation.
D2	CHECK THE REMOTE CLIMATE CONTROL MODULE OUTPUT	
	 Key in ON position. Press the AUTOMATIC button. Measure the voltage between the solar radiation sensor C287 pin 1, circuit 468 (BN) and pin 5, circuit 398 (BK/YE). 	
	A0015935	Yes INSTALL a new RCC module. TEST the system for normal operation. No
		If diagnosing DTC 1260, GO to D3.
D 2	Is the voltage between 4.7 and 5.1 volts?	It diagnosing DTC 1261, GO to D5.
03		4
	 Disconnect: RCC Module C228. 	
		(Continued)

PINPOINT TEST D: DTC B1260 OR DTC B1261 — SOLAR RADIATION SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)



PINPOINT TEST D: DTC B1260 OR DTC B1261 — SOLAR RADIATION SENSOR OPEN CIRCUIT OR SHORT TO GROUND (Continued)



PINPOINT TEST E: DTC U2005 — ACP COMMUNICATION ERROR BETWEEN INTEGRATED CONTROL PANEL AND REMOTE CLIMATE CONTROL MODULE

	Test Step	Result / Action to Take
E1	CHECK CIRCUIT 833 (TN) FOR SHORT TO GROUND	
	 Key in OFF position. Disconnect: Integrated Control Panel C2009. Disconnect: Remote Climate Control Module C228. Disconnect: Rear Control Unit C388b. Measure the resistance between the integrated control panel (ICP) C2009 pin 14, circuit 833 (TN) and ground. 	
	Ļ	Yes GO to E2.
	A0013646	No REPAIR circuit 833 (TN), CLEAR the
	Is the resistance greater than 10,000 ohms?	DTCs. REPEAT the self-test.
E2	CHECK CIRCUIT 833 (TN) FOR SHORT TO VOLTAGE	
	Key in ON position.	
		(Continued)

PINPOINT TEST E: DTC U2005 — ACP COMMUNICATION ERROR BETWEEN INTEGRATED CONTROL PANEL AND REMOTE CLIMATE CONTROL MODULE (Continued)



PINPOINT TEST E: DTC U2005 — ACP COMMUNICATION ERROR BETWEEN INTEGRATED CONTROL PANEL AND REMOTE CLIMATE CONTROL MODULE (Continued)



PINPOINT TEST E: DTC U2005 — ACP COMMUNICATION ERROR BETWEEN INTEGRATED CONTROL PANEL AND REMOTE CLIMATE CONTROL MODULE (Continued)

Test Step	Result / Action to Take
E6 CHECK CIRCUIT 832 (LB/PK) FOR AN OPEN (Continued)	
 Measure the resistance between the ICP C2009 pin 13, circuit 832 (LB/PK) and the RCC module C228 pin 1, circuit 832 (LB/PK). 	
	Yes
A0013649	INSTALL a new integrated control panel (18C858). CLEAR the DTCs. REPEAT the self-test.
 Is the resistance less than 5 ohms? 	REPAIR circuit 832 (LB/PK). CLEAR the DTCs. REPEAT the self-test.

PINPOINT TEST F: NO COMMUNICATION WITH THE REMOTE CLIMATE CONTROL MODULE - EATC

	Test Step	Result / Action to Take
F1	CHECK CIRCUITS 398 (BK/YE) AND 570 (BK/WH)	
	Key in OFF position.Disconnect: Remote Climate Control Module C228.	

PINPOINT TEST F: NO COMMUNICATION WITH THE REMOTE CLIMATE CONTROL MODULE — EATC (Continued)



PINPOINT TEST G: THE EATC SYSTEM IS INOPERATIVE, INTERMITTENT OR INCORRECT OPERATION

Test Step	Result / Action to Take
G1 VERIFY AUTOMATIC OPERATION	
 Key in ON position. With the engine running, press the AUTOMATIC button. Does AUTO and the selected temperature appear in the display window? 	Yes GO to G2. No GO to G11.
G2 PERFORM THE EATC MODULE SELF-TEST	
 Key in ON position. Carry out the remote climate control module self-test. Refer to the Electronic Automatic Temperature Control Module Self-Test in this section. Record the DTCs displayed, if any. Were any DTCs displayed as a result of the EATC self-test? 	Yes REFER to the RCC Module Diagnostic Trouble Code (DTC) Index. CARRY OUT the necessary diagnosis and REPAIR as required. No GO to G3.
G3 CHECK THE VACUUM FLUORESCENT DISPLAY	
 Exit self-test by pressing the DEFROST button. Observe the function symbols displayed on the vacuum fluorescent display. Is the display correct and complete without any missing elements? 	Yes GO to G4. No INSTALL a new RCC module. TEST the system for normal operation.
G4 CHECK THE BLOWER MANUAL OVERRIDE OPERATION	
 Slowly rotate the blower motor speed override control from LO to HI 	Yes GO to G5
 Does the blower motor speed increase smoothly from low speed to high speed? 	No If the blower motor is inoperative, GO to Pinpoint Test O.
	If the blower motor operates continuously in high speed, GO to Pinpoint Test R.
	some speeds, GO to Pinpoint Test U.
G5 VERIFY THE DEFROST OVERRIDE OPERATION	
 Press the override button for DEFROST operation. Is outside air being discharged from the windshield defroster nozzle and the side window demisters? 	Yes GO to G6. No GO to Pinpoint Test I.
G6 VERIFY THE FLOOR OVERRIDE OPERATION	
 Press the override button for FLOOR operation. Is outside air being discharged from the floor duct? 	Yes GO to G7. No GO to Pinpoint Test I.
G7 VERIFY THE VENT OVERRIDE OPERATION	
 Press the override button for VENT operation. Is outside air being discharged from the instrument panel registers? 	Yes GO to G8. No GO to Pinpoint Test I.
G8 VERIFY THE A/C CLUTCH DOES NOT ENGAGE IN THE VENT MODE	
 Press the override button for VENT operation. Does the A/C clutch engage when the VENT override button is pressed? 	Yes REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
	GO to G9.
G9 VERIFY THE MAX A/C OVERRIDE OPERATION	
 Make sure the ambient air temperature is above 5°C (41°F). Press the override button for MAX A/C operation. Is recirculated air being discharged from the instrument panel registers? 	Yes GO to G10. No GO to Pinpoint Test I.
	(Continued)

PINPOINT TEST G: THE EATC SYSTEM IS INOPERATIVE, INTERMITTENT OR INCORRECT OPERATION (Continued)

	Test Step	Result / Action to Take
G10	VERIFY A/C CLUTCH ENGAGEMENT IN THE MAX A/C MODE	
	 Press the override button for MAX A/C operation. Does the A/C clutch engage when the MAX A/C override button is pressed? 	Yes The test is complete. The system is functioning normally. No GO to Pinpoint Test K.
G11	CHECK THE RCC MODULE FUNCTIONS	
	 Press each function button and observe the display. Does the RCC perform and display any functions? 	Yes INSTALL a new RCC module. TEST the system for normal operation. No GO to G12.
G12	CHECK THE VOLTAGE TO THE RCC	
	 Key in OFF position. Disconnect: RCC C228. Key in ON position. Measure the voltage between ground and: RCC module C228 pin 11, circuit 729 (RD/WH). RCC module C228 pin 10, circuit 298 (VT/OG). 	
	A0042618 • Are the voltages greater than 10 volts?	Yes GO to G13. No REPAIR the affected circuit. TEST the system for normal operation.
G13	CHECK THE GROUND CIRCUIT TO THE RCC	
	 Key in OFF position. Measure the resistance between the RCC module C228 pin 8, circuit 570 (BK/YE) and ground. 	
		Yes INSTALL a new RCC module. TEST the system for normal operation.
	A0013651	No
	Is the resistance less than 5 ohms?	REPAIR circuit 570 (BK/YE) for an open. TEST the system for normal operation.

PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL

		l de la constante de
	Test Step	Result / Action to Take
H1	 CHECK THE AIR FLOW IN EACH SETTING Key in ON position. With the engine running, set the blower motor speed to maximum. Check the air flow in each function selector switch setting at engine idle and under acceleration. Is the air flow from only the defroster outlets in each function selector switch setting? 	Yes GO to H2. No GO to H10.
H2	CHECK FOR VACUUM AT THE CHECK VALVE	
	Disconnect the vacuum check valve vacuum source line and check for manifold vacuum and connect the vacuum pump.	
	A0042612 • Is manifold vacuum present at the check valve vacuum source line?	Yes GO to H3. No REPAIR or INSTALL a new check valve vacuum source line. TEST the system for normal operation.
H3	CHECK THE VACUUM CHECK VALVE FOR BLOCKAGE	
	 Reconnect the vacuum source line to the vacuum check valve. Disconnect the vacuum reservoir line and the function selector switch source vacuum line from the vacuum check valve one at a time. 	
	A0015570	Yes GO to H4 .
	 Check for manifold vacuum at the open port on the vacuum check valve. Is manifold vacuum present at the open port on the vacuum check valve? 	No INSTALL a new vacuum check valve (19A563). TEST the system for normal operation.
H4	CHECK THE VACUUM CHECK VALVE	
	Key in OFF position.	
PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)



PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
H7	CHECK THE VACUUM RESERVOIR FOR A LEAK	
	 Connect the vacuum pump reservoir line to the vacuum reservoir. With the vacuum pump connected to the vacuum reservoir line, leak test the vacuum reservoir. 	
	416-D02 416-D02 40015573	Yes INSTALL a new vacuum reservoir (19A566). TEST the system for normal operation. No
	Does the vacuum reservoir leak?	GO to H8.
H8	CHECK THE FUNCTION SELECTOR SWITCH VACUUM SOURCE LINE FOR BLOCKAGE	
	 Disconnect the function selector switch vacuum connector. Connect the vacuum pump to the function selector switch vacuum source line and attempt to pull a vacuum. 	
	416-D002 A0015576	Yes REPAIR or INSTALL a new function selector switch vacuum source line. TEST the system for normal operation.
	 Can a vacuum be pulled on the function selector switch vacuum source line? 	No GO to H9.

PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)

Test Step	Result / Action to Take
H9 CHECK THE FUNCTION SELECTOR SWITCH VACUUM SOURCE LINE FOR LEAKS	
Plug the function selector switch vacuum source line at the function selector switch connection.	
A0015575	
Leak test the function selector switch vacuum source line using the vacuum pump.	
 A0015576 Does the function selector switch vacuum source line leak? 	Yes REPAIR or INSTALL a new function selector switch vacuum source line. TEST the system for normal operation. No INSTALL a new function selector switch (19B888). REFER to Section 412-04. TEST the system for normal operation.
H10 CHECK THE FUNCTION SELECTOR SWITCH FOR BLOCKAGE	
 Disconnect: Function Selector Switch Vacuum Harness. Connect a vacuum pump to the function selector switch vacuum supply port and try to pull a vacuum in each function selector switch position. If the vacuum pump can pull and hold a vacuum, the switch is plugged. If the vacuum pump pulls a vacuum that slowly decays, the hose is restricted. 	
A0015578	Yes INSTALL a new function selector switch (19B888). REFER to Section 412-04. TEST the system for normal operation. No
Is the switch plugged or restricted?	GO to H11.
	(Continued)

PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)

Test Step	Result / Action to Take
H11 LEAK TEST THE FUNCTION SELECTOR SWITCH	
 Connect a vacuum pump to the function selector switch vacuum supply port and plug each control port. 	
A0015578	Yes INSTALL a new function selector switch (19B888) BEEEB to Section 412-04
 At each function selector switch position apply 51 kPa (15 in-Hg) of vacuum. 	TEST the system for normal operation.
 Does the vacuum drop exceed 3.37 kPa (1 in-Hg) per minute? 	No GO to H12.
H12 CHECK THE VACUUM HOSE	
 Disconnect the suspect hose. Connect a vacuum pump to each hose and attempt to pull and hold a vacuum. 	
0100010	Ves
AL0157-A	GO to H13.
 Does the vacuum in any hose drop exceed 3.37 kPa (1 in-Hg) per minute? 	No GO to H14.
H13 CHECK THE VACUUM CONTROL MOTOR	
Disconnect: Vacuum Control Motor.	

PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)

Test Step	Result / Action to Take
H13 CHECK THE VACUUM CONTROL MOTOR (Continued)	
 Connect a vacuum pump to the affected vacuum control motor. Apply 51 kPa (15 in-Hg) of vacuum. 	
At 24	
	Yes INSTALL a new vacuum control motor (18A318). REFER to Section 412-04. TEST the system for normal operation.
AL0136-A	No
 Does the vacuum drop exceed 1.68 kPa (0.5 in-Hg) per minute? 	harness (19C827). TEST the system for normal operation.
H14 CHECK THE VACUUM CONTROL MOTOR HOSES FOR BLOCKAGE	
 Disconnect: Vacuum Control Motors. Connect a vacuum pump to each hose and try to pull a vacuum. If the vacuum pump can pull and hold a vacuum, the hose is plugged. If the vacuum pump pulls a vacuum that slowly decays, the hose is restricted. 	
SI V	
AL0157-A	Yes REPAIR or INSTALL a new vacuum harness (19C827). TEST the system for normal operation.
 Is the hose plugged or restricted? 	No GO to H15.
F	(Continued)

PINPOINT TEST H: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
H15	CHECK THE VACUUM CONTROL MOTOR INSTALLATION	
	 Check the attachment of the vacuum control motor arm to the damper door. 	
		Yes REPAIR the damper door. TEST the system for normal operation.
	AL0158-A	No
	 Is the vacuum control motor arm attached to the door or door crank arm? 	CONNECT the vacuum control motor arm to the door crank arm. TEST the system for normal operation.

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET - EATC

	Test Step	Result / Action to Take
11	CHECK THE AIR FLOW IN EACH SETTING	
	 Key in ON position. With the engine running, check the air flow in each manual override setting on the EATC module during engine idle and under acceleration. Is the air flow correct in each manual override setting? 	Yes The system is operating normally. No If the air flow is from the defrost outlet only in all settings, GO to 12.
		If the air flow is incorrect in one setting only, NOTE the non-functional setting. GO to 110.
		If the air flow is incorrect in MAX only, GO to 114.
12	CHECK FOR VACUUM AT THE CHECK VALVE	
	Disconnect the vacuum check valve vacuum source line and connect the vacuum pump.	
13	OFFICIENT ACTION CHECK VALUE FOR BLOCKAGE	Yes GO to 13. No REPAIR or INSTALL a new check valve vacuum source line. TEST the system for normal operation.
13		4

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

	Test Step	Result / Action to Take
13	CHECK THE VACUUM CHECK VALVE FOR BLOCKAGE (Continued)	
	Disconnect the vacuum reservoir line and the EATC module vacuum line from the vacuum check valve one at a time.	
	A0015570	Yes
	 Check for manifold vacuum at the open port on the vacuum check valve. In manifold vacuum present at the open port on the vacuum 	GO to 14. No
	check valve?	TEST the system for normal operation.
14	CHECK THE VACUUM CHECK VALVE	
	 Key in OFF position. Disconnect: A/C Vacuum Check Valve. Connect the vacuum pump to the vacuum check valve and attempt to pull a vacuum. 	
	416-D002 A0015571	Yes GO to 15. No
	Can a vacuum be pulled on the vacuum check valve?	TEST the system for normal operation.
15	CHECK THE VACUUM RESERVOIR LINE FOR BLOCKAGE	
	• Disconnect the vacuum reservoir line at the vacuum reservoir.	

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

	Test Step	Result / Action to Take
15 C	HECK THE VACUUM RESERVOIR LINE FOR BLOCKAGE	
(0	Continued)	
•	Connect the vacuum pump to the vacuum reservoir line at the vacuum check valve connection and attempt to pull a vacuum.	
	416-D002 416-D002 40015573	Yes REPAIR or INSTALL a new vacuum reservoir line. TEST the system for normal operation.
•		
	Plug the vacuum reservoir line at the vacuum reservoir	
	connection.	
•	Leak test the vacuum reservoir line using the vacuum pump.	
•	416-D002 416-D02 416-D0	Yes REPAIR or INSTALL a new vacuum reservoir line. TEST the system for normal operation. No GO to 17.
17 C	HECK THE VACUUM RESERVOIR FOR A LEAK	
•	Connect the vacuum pump reservoir line to the vacuum reservoir. With the vacuum pump connected to the vacuum reservoir line, leak test the vacuum reservoir.	
	416-D002 416-D002 40015573	Yes INSTALL a new vacuum reservoir. TEST the system for normal operation. No
•	Does the vacuum reservoir leak?	GO to 18.
		(Continued)

2003 Taurus/Sable, 8/2002

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

	Test Step	Result / Action to Take
18	CHECK THE EATC MODULE VACUUM SOURCE LINE FOR	
	 Disconnect the EATC module vacuum connector. Connect the vacuum pump to the EATC module vacuum source line and attempt to pull a vacuum. 	
	 Can a vacuum be pulled on the EATC module vacuum 	Yes REPAIR or INSTALL a new EATC module vacuum source line. TEST the system for normal operation. No GO to 19.
19	CHECK THE EATC MODULE VACUUM SOURCE LINE FOR LEAKS	
	 Plug the EATC module vacuum source line at the EATC module connection. A0015577 	
	 Leak test the EATC module vacuum source line using the vacuum pump. <u>416-D002</u> <u>416-D002</u> <u>40015576</u> 	Yes REPAIR or INSTALL a new EATC module vacuum source line. TEST the system for normal operation.
	Does the EATC module vacuum source line leak?	INSTALL a new EATC module (19980). TEST the system for normal operation.
		(Continued)

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

Test Step	Result / Action to Take
110 CHECK THE VACUUM CONTROL MOTOR LINE FOR	
 BLOCKAGE Key in OFF position. Disconnect the EATC module vacuum connector. Disconnect the vacuum line from the appropriate vacuum control motor noted in step 11. Connect the vacuum pump to the appropriate vacuum control motor line noted in step 11, and attempt to pull a vacuum. 	
AL0157-A	Yes REPAIR or INSTALL a new plenum vacuum harness (19C827). TEST the system for normal operation. No
111 CHECK THE VACUUM CONTROL MOTOR LINE FOR LEAKS	
 Plug the vacuum control motor line at the vacuum control motor connection. Leak test the vacuum control motor line using the vacuum pump. 	
AL0157-A	Yes REPAIR or INSTALL a new vacuum harness. TEST the system for normal operation. No
Does the vacuum control motor line leak?	GO to 112.

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

Test Step	Result / Action to Take
I12 CHECK THE VACUUM CONTROL MOTOR FOR LEAKS AND CORRECT OPERATION	
 Connect the vacuum pump to the appropriate vacuum control motor and pull a vacuum. 	
A A A	
	Yes GO to I13. No
AL0136-A	INSTALL a new vacuum control motor (18A318). TEST the system for normal
 Inspect the mode door linkage and verify correct movement of the mode door. Is the mode door or mode door linkage broken, binding or otherwise obstructed? 	Yes REPAIR the mode door or mode door linkage as necessary. TEST the system for normal operation. No INSTALL a new EATC module. TEST the
	system for normal operation.
114 CHECK THE AIR INLET DOOR VACUUM CONTROL MOTOR LINE FOR BLOCKAGE	
 Key in OFF position. Disconnect the air inlet door vacuum control motor vacuum connector. Disconnect the EATC module vacuum connector and attempt to pull a vacuum on the RECIRC vacuum control motor line using the vacuum pump. 	
A0036133	Yes REPAIR or INSTALL a new plenum vacuum harness (19C827). TEST the system for normal operation.
Can a vacuum be pulled on the air inlet door vacuum control motor line?	No GO to 115.
115 CHECK THE AIR INLET DOOR VACUUM CONTROL MOTOR LINE FOR LEAKS.	
 Plug the air inlet door vacuum control motor line at the RECIRC vacuum control motor connection. 	

PINPOINT TEST I: INCORRECT/ERRATIC DIRECTION OF AIR FLOW FROM OUTLET — EATC (Continued)

	Test Step	Result / Action to Take
l15	CHECK THE AIR INLET DOOR VACUUM CONTROL MOTOR	
	LINE FOR LEAKS. (Continued)	-
	 Leak test the air inlet door vacuum control motor line using the vacuum pump. 	
	A0036133	Yes REPAIR or INSTALL a new vacuum harness (19C827). TEST the system for normal operation.
	Does the air inlet door vacuum control motor line leak?	No GO to 116
I16	CHECK THE AIR INLET DOOR VACUUM CONTROL MOTOR	
	FOR LEAKS AND CORRECT OPERATION	
	 Connect the vacuum pump to the air inlet door vacuum control motor and pull a vacuum 	
		Yes GO to 117.
	AL0136-A	No INSTALL a new air inlet door vacuum
	Does the air inlet door vacuum control motor operate and hold a vacuum?	control motor (18A318). TEST the system for normal operation.
l17	INSPECT THE AIR INLET DOOR LINKAGE AND MOVEMENT	
	 Inspect the air inlet door linkage and verify correct movement of the door. Is the air inlet door or air inlet door linkage broken, binding or otherwise obstructed? 	Yes REPAIR the air inlet door or air inlet door linkage as needed. TEST the system for correct operation.
		No INSTALL a new EATC module (19980). TEST the system for normal operation.

PINPOINT TEST J: INSUFFICIENT, ERRATIC, OR NO HEAT — MANUAL CLIMATE CONTROL AND EATC

	Test Step	Result / Action to Take
J1	CHECK FOR CORRECT COOLANT LEVEL	
	 Key in OFF position. Check the engine coolant level when hot and cold. Is the engine coolant at the correct levels (hot and cold)? 	Yes GO to J2. No GO to J3.

PINPOINT TEST J: INSUFFICIENT, ERRATIC, OR NO HEAT — MANUAL CLIMATE CONTROL AND EATC (Continued)

[
	lest Step	Result / Action to Take
J2	CHECK FOR HOT COOLANT AT THE HEATER CORE INLET HOSE	
	 WARNING: The heater core inlet hose will become too hot to handle and may cause serious burns if the system is working correctly. Allow the engine to reach normal operating temperature. Feel the heater core inlet hose. 	
		Yes GO to J4.
	Is the heater core inlet hose too hot to handle?	No REFER to Section 303-03 to check the cooling system function.
.13	CHECK THE ENGINE COOLING SYSTEM FOR LEAKS	
	 Fill the engine cooling system to the specified level. Pressure check the cooling system, including the pressure relief cap. Refer to Section 303-03. It is not necessary to check the components separately at this time. Does the engine cooling system, including the pressure relief cap, hold pressure? 	Yes GO to J4. No REPAIR the engine cooling system leak. TEST the system for normal operation.
J4	CHECK FOR HOT COOLANT AT THE HEATER CORE OUTLET HOSE	
	 WARNING: The heater core outlet hose will become too hot to handle and may cause serious burns if the system is working correctly. Allow the engine to reach normal operating temperature. Feel the heater core outlet hose. 	
	A0015941	Yes CARRY OUT the heater core component test. REFER to Heater Core under Component Tests in this section to determine whether a plugged or partially plugged condition exists. No Vehicles with manual climate control, GO to Pinpoint Test M. Vehicles with EATC. GO to Pinpoint Test
	 Is the heater core outlet hose cool or cold? 	A.

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY

NOTE: Before carrying out the following test, diagnose any PCM DTCs.

NOTE: Before carrying out the following test, make sure that the A/C system pressure is above 290 kPa (42 psi). If the pressure is below 290 kPa (42 psi), refer to Fluorescent Dye Leak Detection in this section.

	Test Step	Result / Action to Take
K1	CHECK THE A/C PRESSURE PCM PID	
	 Key in ON position. Enter the following diagnostic mode on the scan tool: A/C Pressure PCM PID. With the manifold gauge set connected, compare the pressure readings of the manifold gauge set and the A/C pressure PID. Are the pressure values of the manifold gauge set and the A/C pressure PID similar? 	Yes GO to K2. No INSTALL a new A/C pressure transducer. TEST the system for normal operation.
K2	CHECK THE A/C EVAPORATOR TEMPERATURE PID	
	 Allow the vehicle exterior and interior to stabilize to an ambient temperature above 16°C (60°F). Enter the following diagnostic mode on the scan tool: A/C Evaporator Discharge Temperature PCM PID. Does the A/C evaporator discharge temperature PID read similar to the ambient temperature? 	Yes GO to K3. No INSTALL a new A/C evaporator discharge temperature sensor. TEST the system for normal operation.
K3	CHECK PID ACCS WITH THE A/C OFF	
	 Key in ON position. With the engine running, place the function selector switch to the OFF position or press the OFF manual override button on the remote climate control (RCC) module. Enter the following diagnostic mode on the scan tool: PCM PID ACCS. Does the PCM PID ACCS read ON? 	Yes REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual. No GO to K4.
K4	CHECK PID WAC WITH THE A/C OFF	
	 Enter the following diagnostic mode on the scan tool: PCM PID WAC. Does the PCM PID WAC read ON? 	Yes REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual. No GO to K5.
K5	CHECK THE PID ACCS WITH THE A/C ON	
	 Enter the following diagnostic mode on the scan tool: PCM PID ACCS. Place the function selector switch in the MAX A/C position. Does the PCM PID ACCS read ON? 	Yes GO to K6. No GO to K7.
K6	CHECK THE PID WAC WITH THE A/C ON	
	 Enter the following diagnostic mode on the scan tool: PCM PID WAC. Does the PCM PID WAC read ON? 	Yes GO to K16. No REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual.
K7	CHECK THE A/C PRESSURE CUTOFF SWITCH VOLTAGE	
	 Key in OFF position. Disconnect: A/C Pressure Cutoff Switch C1062. Key in ON position. 	

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)



2003 Taurus/Sable, 8/2002

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)

Test Step	Result / Action to Take
K10 CHECK THE VOLTAGE AT THE FUNCTION SELECTOR SWITCH	
 Key in OFF position. Remove the climate control assembly. Refer to Section 412-04. Disconnect: Function Selector Switch C294b. Key in ON position. Measure the voltage between the function selector switch C294b pin 1, circuit 1087 (OG) and ground. 	
	Yes GO to K11. No BEPAIR circuit 1087 (OG), TEST the
 Is the voltage greater than 10 volts? 	system for normal operation.
K11 CHECK CIRCUIT 348 (VT) FOR AN OPEN	
 Key in OFF position. Measure the resistance between the function selector switch C294b pin 2, circuit 348 (VT) and the low charge switch C130 pin 1, circuit 348 (VT). 	
	Yes INSTALL a new function selector switch. REFER to Section 412-04. TEST the system for normal operation. No REPAIR circuit 348 (VT). TEST the
Is the resistance less than 5 ohms?	system for normal operation.
K12 CHECK CIRCUIT 348 (VT) FOR AN OPEN	-

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)

Test Step	Result / Action to Take
K12 CHECK CIRCUIT 348 (VT) FOR AN OPEN (Continued)	
• Measure the resistance between the RCC C228 pin 13, circuit 348 (VT) and the low charge switch C130 pin 1, circuit 348 (VT).	
A0013803 • Is the resistance less than 5 ohms?	Yes INSTALL a new RCC module. REFER to Section 412-04. TEST the system for normal operation. No REPAIR circuit 348 (VT). TEST the system for normal operation.
K13 CHECK THE A/C SYSTEM PRESSURE	
 Key in OFF position. Connect the manifold gauge set. Refer to Manifold Gauge Set Connection in this section. Is the pressure reading between 345 kPa (50 psi) and 1724 kPa (250 psi)? 	Yes INSTALL a new low charge switch. TEST the system for normal operation. No CHECK the system for refrigerant leaks. REFER to Electronic Leak Detection and Fluorescent Dye Leak Detection in this section.
K14 CHECK THE A/C PRESSURE CUTOFF SWITCH	
 Key in OFF position. Connect a fused jumper lead between the A/C pressure cutoff switch C1062 pin 4, circuit 441 (RD/YE) and pin 1, circuit 879 (DG/WH). 	
	Yes
A0013805	(19D594). TEST the system for normal operation.
 Key in START position. Does the A/C compressor operate? 	GO to K15.
K15 CHECK CIRCUIT 879 (DG/WH)	
 Key in OFF position. Remove the fused jumper lead from the A/C pressure cutoff switch C1062. Disconnect: PCM C175. 	
	(Continued)

2003 Taurus/Sable, 8/2002

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)

Test Step	Result / Action to Take
K15 CHECK CIRCUIT 879 (DG/WH) (Continued)	
 Measure the resistance between the A/C pressure cutoff switch C1062 pin 1, circuit 879 (DG/WH) and the PCM C175 pin 41, circuit 879 (DG/WH). 	
A0042075	Yes INSTALL a new PCM. REFER to Section 303-14. No
 Is the resistance less than 5 ohms? 	REPAIR circuit 879 (DG/WH). TEST the system for normal operation.
K16 CHECK THE VOLTAGE AT THE A/C COMPRESSOR CLUTCH	
 Key in OFF position. Disconnect: A/C Compressor Clutch Field Coil C100. Key in ON position. Measure the voltage between the A/C compressor clutch field coil C100, circuit 347 (BK/YE) and ground. 	
A0013807	Yes GO to K17.
Is the voltage greater than 10 volts?	GO to K18.
K17 CHECK THE GROUND AT THE A/C COMPRESSOR CLUTCH	
Key in OFF position.]

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)

Test Step	Result / Action to Take
K17 CHECK THE GROUND AT THE A/C COMPRESSOR CLUTCH FIELD COIL (Continued)	
 Measure the resistance between the A/C compressor clutch field coil C100, circuit 57 (BK) and ground. 	
	GO to K20.
A0013808 Is the resistance less than 5 ohms?	No REPAIR circuit 57 (BK). TEST the system for normal operation.
K18 CHECK CIRCUIT 883 (PK/LB)	
 Key in OFF position. Disconnect: A/C Control Relay. Measure the voltage between the A/C control relay socket pin 3, circuit 883 (PK/LB) and ground. 	
	Ves
A0013810	GO to K19. No
 Is the voltage greater than 10 volts? 	REPAIR circuit 883 (PK/LB). TEST the system for normal operation.
K19 CHECK CIRCUIT 347 (BK/YE)	
 Measure the resistance between the A/C control relay socket pin 5, circuit 347 (BK/YE) and the A/C compressor clutch field coil C100, circuit 347 (BK/YE). 	
	Yes
A0013809	No
Is the resistance less than 5 ohms?	REPAIR circuit 347 (BK/YE). TEST the system for normal operation.

PINPOINT TEST K: THE A/C DOES NOT OPERATE/DOES NOT OPERATE CORRECTLY (Continued)



PINPOINT TEST L: THE A/C IS ALWAYS ON

Test Step	Result / Action to Take
L1 CHECK PID WACF WITH THE A/C OFF	
 Key in ON position. Place the function selector switch to the OFF position or press the OFF manual override button . Enter the following diagnostic mode on the scan tool: PCM PID WACF. Does the PCM PID WACF read YES? 	Yes REPAIR circuit 331 (PK/YE). TEST the system for normal operation. No GO to L2.
L2 CHECK PID ACCS WITH THE A/C OFF	
 Enter the following diagnostic mode on the scan tool: PCM PID ACCS. Does the PCM PID ACCS read ON? 	Yes GO to L3. No GO to L7.
L3 CHECK FOR VOLTAGE AT THE LOW CHARGE SWITCH	
 Key in OFF position. Disconnect: Low Charge Switch C130. Key in ON position. Measure the voltage between the low charge switch C130 pin 1, circuit 348 (VT) and ground. 	
	Yes
A0013801	No
Is the voltage greater than 10 volts?	GO to L5.
 Key in OFF position. Remove the climate control assembly. Refer to Section 412-04. Disconnect: Function Selector Switch C294b or RCC module C228. Key in ON position. Measure the voltage between the low charge switch C130 pin 1, circuit 348 (VT) and ground. 	
	Yes REPAIR circuit 348 (VT) for a short to voltage. TEST the system for normal operation. No
A0013801	INSTALL a new function selector switch.
Is the voltage greater than 10 volts?	system for normal operation.
L5 CHECK CIRCUIT 441 (RD/YE)	
 Key in OFF position. Disconnect: A/C Pressure Cutoff Switch C1062. Key in ON position. 	
	(Continued)

2003 Taurus/Sable, 8/2002

PINPOINT TEST L: THE A/C IS ALWAYS ON (Continued)



PINPOINT TEST L: THE A/C IS ALWAYS ON (Continued)

	Test Step	Result / Action to Take
L8	CHECK CIRCUIT 347 (BK/YE)	
	 Key in OFF position. Disconnect: A/C Control Relay. Key in ON position. Measure the voltage between the A/C compressor clutch field coil C100, circuit 347 (BK/YE) and ground. 	
	A0013807	Yes REPAIR circuit 347 (BK/YE). TEST the system for normal operation.
	 Is the voltage greater than 10 volts? 	INSTALL a new A/C control relay. TEST the system for normal operation.
L9	CHECK THE A/C COMPRESSOR CLUTCH AIR GAP	
	 Key in OFF position. Measure the A/C compressor clutch air gap at three equally spaced locations between the clutch hub and the A/C compressor clutch pulley. 	
	0.35-0.75 mm (0.014-0.030 in)	Yes ADJUST the A/C compressor clutch field coil. REFER to Air Conditioning (A/C) Clutch Air Gap Adjustment in this section. TEST the system for normal operation.
	 Is the A/C compressor clutch air gap greater than 0.75 mm (0.030 in)? 	NO INSTALL a new A/C compressor clutch field coil. REFER to Section 412-03. TEST the system for normal operation.

PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS-MANUAL CLIMATE CONTROL

	Test Step	Result / Action to Take
M1	CHECK THE VOLTAGE TO THE TEMPERATURE BLEND DOOR ACTUATOR MOTOR	
	 Key in OFF position. Disconnect: Temperature Blend Door Actuator Motor C289. Key in ON position. 	

PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS—MANUAL CLIMATE CONTROL (Continued)



PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS—MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
M4	CHECK CIRCUITS 436 (RD/LG) AND 438 (RD/WH) FOR A SHORT TOGETHER	
	 Disconnect: Temperature Control Potentiometer C294c. Measure the resistance between temperature blend door actuator C289 pin 6, circuit 436 (RD/LG) and pin 4, circuit 438 (RD/WH). 	
		Yes REPAIR circuits 436 (RD/LG) and 438 (RD/WH) for a short together. TEST the system for normal operation. No
	Is the resistance less than 5 ohms?	potentiometer. REFER to Section 412-04.
M5	CHECK CIRCUITS 436 (RD/LG) AND 438 (RD/WH) FOR AN	
	 Disconnect: Temperature Control Potentiometer C294c. Measure the resistance between temperature blend door actuator C289 pin 6, circuit 436 (RD/LG) and temperature control potentiometer C294c pin 1, circuit 436 (RD/LG), and between temperature blend door actuator C289 pin 4, circuit 438 (RD/WH) and temperature control potentiometer C294c pin 3, circuit 438 (RD/WH). 	
		Vac
		INSTALL a new temperature control potentiometer. REFER to Section 412-04. TEST the system for normal operation.
	Are the resistances less than 5 ohms?	NO REPAIR the affected circuit. TEST the system for normal operation.

PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS—MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
M6	CHECK THE TEMPERATURE CONTROL POTENTIOMETER OPERATION	
	 Measure the resistance between temperature blend door actuator C289 pin 6, circuit 436 (RD/LG) and pin 3, circuit 437 (YE/LG) while rotating the temperature control potentiometer from full WARM to full COOL. 	
		Yes
	AW0024-A	No
	Does the resistance vary between 150 and 4,800 ohms?	GO to M7.
M7	 CHECK CIRCUIT 437 (YE/LG) FOR AN OPEN Disconnect: Temperature Control Potentiometer C294c. Measure the resistances between actuator C289 pin 3, circuit 437 (YE/LG) and temperature control potentiometer C294c pin 2, circuit 437 (YE/LG). 	
		Yes GO to M8.
	Is the resistance less than 5 ohms?	NO REPAIR circuit 437 (YE/LG) for an open. TEST the system for normal operation
<u> </u>		(Continued)

2003 Taurus/Sable, 8/2002

PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS—MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
M8	CHECK CIRCUITS 436 (RD/LG) AND 437 (YE/LG) FOR A SHORT	
	 Measure the resistance between temperature blend door actuator C289 pin 6, circuit 436 (RD/LG) and pin 3, circuit 437 (YE/LG). 	
	Is the resistance less than 5 ohms?	Yes REPAIR circuits 436 (RD/LG) and 437 (YE/LG) for a short together. TEST the system for normal operation. No INSTALL a new temperature control potentiometer. REFER to Section 412-04. TEST the system for normal operation.
M9	CHECK CIRCUITS 436 (RD/LG) AND 437 (YE/LG) FOR A SHORT	
	 Disconnect: Temperature Control Potentiometer C294c. Measure the resistances between temperature blend door actuator C289 pin 6, circuit 436 (RD/LG) and ground, and between temperature blend door actuator C289 pin 3, circuit 437 (YE/LG) and ground. 	
	A0042535	Yes REPAIR the affected circuit for a short to ground. TEST the system for normal operation. No
	• Are the resistances less than 5 ohms?	GO to M10.
M10	CHECK CIRCUITS 437 (YE/LG) AND 438 (RD/WH) FOR A SHORT TO GROUND	
	 Disconnect: Temperature Control Potentiometer C294c. Key in ON position. 	
L	· · · ·	

PINPOINT TEST M: NO OPERATION IN ALL TEMPERATURE SETTINGS—MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
M10	CHECK CIRCUITS 437 (YE/LG) AND 438 (RD/WH) FOR A SHORT TO GROUND (Continued)	
	 Measure the voltages between temperature blend door actuator C289 pin 4, circuit 438 (RD/WH) and ground, and between temperature blend door actuator C289 pin 3, circuit 437 (YE/LG) and ground. 	
	A0042536	Yes REPAIR the affected circuit for a short to power. TEST the system for normal operation. No GO to M11
M11	CHECK FOR A BINDING, STUCK OR BROKEN BLEND DOOR	
	 Key in OFF position. Remove the actuator. Refer to Section 412-04. Inspect for a binding, stuck or broken blend door or linkage. Is there a binding, stuck or broken blend door or linkage condition? 	Yes REPAIR the blend door/linkage. REFER to Section 412-04. TEST the system for normal operation. No INSTALL a new temperature blend door actuator. REFER to Section 412-04. TEST the system for normal operation.

PINPOINT TEST N: THE BLOWER MOTOR DOES NOT OPERATE — MANUAL CLIMATE CONTROL

Test Step	Result / Action to Take
N1 CHECK THE BLOWER MOTOR	
 Key in OFF position. Disconnect: Blower Motor C2004. Connect battery voltage and ground to the blower motor. 	
рмо733-B	Yes GO to N2. No
Does the blower motor operate?	INSTALL a new blower motor (19805). TEST the system for normal operation.
N2 CHECK FOR VOLTAGE TO THE BLOWER MOTOR	
 Key in ON position. Place the function selector switch in the floor position. 	

PINPOINT TEST N: THE BLOWER MOTOR DOES NOT OPERATE — MANUAL CLIMATE CONTROL (Continued)



PINPOINT TEST N: THE BLOWER MOTOR DOES NOT OPERATE — MANUAL CLIMATE CONTROL (Continued)



PINPOINT TEST N: THE BLOWER MOTOR DOES NOT OPERATE — MANUAL CLIMATE CONTROL (Continued)



PINPOINT TEST O: THE BLOWER MOTOR IS INOPERATIVE - EATC

Test Step	Result / Action to Take
O1 CHECK THE BLOWER MOTOR SPEED CONTROL SUPPLY VOLTAGE	
 Key in OFF position. Disconnect: Blower Motor Speed Control C271a. Key in ON position. Press the AUTOMATIC button on the remote climate control (RCC) module. Measure the voltage between the blower motor speed control C271a pin 1, circuit 371 (PK/WH) and ground. 	
A0013863 • Is the voltage greater than 10 volts?	Yes GO to 07. No GO to 02.
O2 CHECK THE BLOWER MOTOR RELAY SUPPLY VOLTAGE, SWITCH SIDE	
 Key in OFF position. Disconnect: Blower Motor Relay. Measure the voltage between the blower motor relay socket pin 87 and ground. 	
A0013861	Yes GO to O3. No
Is the voltage greater than 10 volts?	REPAIR the affected circuit. TEST the system for normal operation.
O3 CHECK THE BLOWER MOTOR RELAY SUPPLY VOLTAGE, COIL SIDE	
Key in ON position.	1

PINPOINT TEST O: THE BLOWER MOTOR IS INOPERATIVE — EATC (Continued)



2003 Taurus/Sable, 8/2002

PINPOINT TEST O: THE BLOWER MOTOR IS INOPERATIVE — EATC (Continued)

Test Step	Result / Action to Take
O6 CHECK THE RCC MODULE	
 Connect: RCC Module C228. Key in ON position. Depress the AUTO button. Measure the voltage between blower motor relay socket pin 85 and blower motor relay socket pin 86, circuit 275 (YE). 	
A0038291 • Is the voltage greater than 10 volts?	Yes INSTALL a new blower motor relay. TEST the system for normal operation. No INSTALL a new RCC module. TEST the system for normal operation.
O7 BYPASS THE BLOWER MOTOR RELAY	
 Key in OFF position. Disconnect: Blower Motor Speed Control C271b. Key in ON position. Connect a fused (40A) 12 gauge jumper lead between the blower motor speed control C271a pin 1, circuit 371 (PK/WH) and the blower motor speed control C271b, circuit 371 (OG); connect a second fused (40A) jumper lead between the blower motor speed control C271a pin 2, circuit 57 (BK) and the blower motor speed control C271b, circuit 261 (BK). 	
A0015042	Yes GO to 011 . No GO to 08 .
O8 CHECK CIRCUIT 371 (PK/WH)	
 Key in OFF position. Disconnect: Blower Motor C2006. 	
	I

PINPOINT TEST O: THE BLOWER MOTOR IS INOPERATIVE — EATC (Continued)



PINPOINT TEST O: THE BLOWER MOTOR IS INOPERATIVE — EATC (Continued)

	Test Step	Result / Action to Take
011	CHECK THE BLOWER MOTOR SPEED CONTROL INPUT	
	SIGNAL	
	Key in OFF position.	
	Remove the fused jumper leads from the blower motor speed control C271a and C271b	
	Connect: Blower Motor Speed Control C271a	
	Key in ON position.	
	 Press the MAX A/C manual override button and adjust the 	
	blower speed to maximum.	
	C271a pin 3, circuit 776 (OG/BK) and ground by back-probing	
	the blower motor speed control C271a pin 3, circuit 776	
	(OG/BK).	
	\square \square \square \square \square	
		Yes
		INSTALL a new blower motor speed
		control. IEST the system for normal
	NUU17446	
	 Is the voltage approximately 5 volts? 	GO to 012
012		
012	Disconnect: BCC Medule C228	
	 Disconnect: NOC Module C226. Measure the resistance between the blower motor speed control 	
	C271a pin 3, circuit 776 (OG/BK) and ground.	
		Yes
	=	INSTALL a new RCC module. TEST the
		system for normal operation.
	A0013876	
	• Is the resistance greater than 10,000 shme?	REPAIR circuit 776 (OG/BK). TEST the
	• is the resistance greater than 10,000 onins?	system for normal operation.

PINPOINT TEST P: THE BLOWER MOTOR DOES NOT OPERATE CORRECTLY — MANUAL CLIMATE CONTROL

	Test Step	Result / Action to Take
P1	CHECK THE BLOWER MOTOR SWITCH	
	 Key in OFF position. Disconnect: Blower Motor Switch C294a. Measure the resistance between the blower motor switch pins, component side, in the following blower motor switch positions: 	
PINPOINT TEST P: THE BLOWER MOTOR DOES NOT OPERATE CORRECTLY — MANUAL CLIMATE CONTROL (Continued)

Test Step		Result / Action to Take
P1 CHECK THE BLOWER MOTOR SWITCH (Continued)		_
Switch Position	Continuity Between Pins	
low	none	
med-low	2 and 3	
med-high	2, 3, and 4	
high	1, 2, and 4	
A0013877 • Are the resistances less the expected and greater than provide the resistance of the provide the resistance between the resistance between the resistance between the blower motor resistance between	an 5 ohms when continuity is 10,000 ohms for all others? (X), 752 (YE/RD), AND 754 (LG/WH) esistor C293. veen the blower motor switch C294a or C293 as follows:	Yes GO to P2. No INSTALL a new blower motor switch (18578). TEST the system for normal operation.
Blower Motor Switch C294a	Blower Motor Resistor C293	
pin 3, circuit 57 (BK)	pin 3, circuit 57 (BK)	
pin 4, circuit 261 (OG/BK)	pin 2, circuit 261 (OG/BK)	
pin 1, circuit 754 (LG/WH)	pin 1, circuit 754 (LG/WH)	
pin 2, circuit 752 (YE/RD)	pin 4, circuit 752 (YE/RD)	
		Yes GO to P3. No REPAIR the affected circuit(s). TEST the
		(Continued)

PINPOINT TEST P: THE BLOWER MOTOR DOES NOT OPERATE CORRECTLY — MANUAL CLIMATE CONTROL (Continued)

Test Step		Result / Action to Take
P3 CHECK CIRCUITS 261 (OG/BK), 752 (YE/RD), AND 754 (LG/WH) FOR A SHORT		
Measure the resistances between the blower motor switch C294a:		
 pin 1, circuit 754 (LG/WH) and ground. pin 2, circuit 752 (YE/RD) and ground. pin 4, circuit 261 (OG/BK) and ground. 		
		Yes GO to P4.
A0013879	÷	No
Are the resistances greate	r than 10,000 ohms?	REPAIR the affected circuit(s). TEST the system for normal operation.
P4 CHECK THE BLOWER MOTO	R RESISTOR	
Measure the resistance between the blower motor resistor pins,		
component side, as follows:		
Blower Motor Resistor Pins	Resistance	
2 and 3	2.2 ohms	
1 and 3	0.9 ohms	
1 and 2	1.4 ohms	
2 and 4	1.9 ohms	
Aver the resistances as indicated?		
A0013880	icated?	Yes INSTALL a new blower motor (19805). TEST the system for normal operation. No INSTALL a new blower motor resistor (19A706). TEST the system for normal operation

PINPOINT TEST Q: THE BLOWER MOTOR OPERATES CONTINUOUSLY IN HIGH SPEED — MANUAL CLIMATE CONTROL

	Test Step	Result / Action to Take
Q1	CHECK THE BLOWER MOTOR GROUND	
	 Key in OFF position. Disconnect: Blower Motor Resistor C293. Key in ON position. Place the function selector switch in the floor position and the blower motor switch in the low position. Does the blower motor speed operate in high speed? 	Yes GO to Q2. No INSTALL a new blower motor resistor (19A706). TEST the system for normal operation.
Q2	CHECK CIRCUIT 261 (OG/BK)	
	 Key in OFF position. Measure the resistance between the blower motor resistor C293 pin 2, circuit 261 (OG/BK) and pin 3, circuit 57 (BK). 	
		N
		Yes REPAIR circuit 261 (OG/BK). TEST the system for normal operation.
	• Is the resistance greater than 10.000 ohms?	INSTALL a new blower motor switch (18578). TEST the system for normal operation.

PINPOINT TEST R: THE BLOWER MOTOR OPERATES CONTINUOUSLY IN HIGH SPEED — EATC

	Test Step	Result / Action to Take
R1	CHECK BLOWER OPERATION	
	 Key in ON position. Press the override button for MAX A/C operation and rotate the blower motor speed override control fully down. Does the blower speed reduce? 	Yes The system is functioning normally. No GO to R2.
R2	CHECK CIRCUIT 776 (OG/BK) FOR VOLTAGE	
	 Press the OFF button. Measure the voltage between the blower motor speed control C271a pin 3, circuit 776 (OG/BK) and ground by backprobing at the connector. 	
	N0017446	Yes GO to R4.
	 Is the voltage greater than 0 volts? 	GO to R3.
R3	CHECK BLOWER MOTOR SPEED CONTROL INPUT VOLTAGE	
	 Key in OFF position. Disconnect: Remote Climate Control (RCC) Module C228. Key in ON position. 	
		(Continued)

PINPOINT TEST R: THE BLOWER MOTOR OPERATES CONTINUOUSLY IN HIGH SPEED — EATC (Continued)

	Test Sten	Besult / Action to Take
P3		Hesuit / Action to Take
no	(Continued)	
1	 Measure the voltage between RCC module C228 pin 24, circuit 776 (OG/BK) and ground. 	
	A0042613 - S volts?	Yes INSTALL a new RCC module. TEST the system for normal operation. No INSTALL a new blower motor speed control module. TEST the system for normal operation.
R4	CHECK THE BLOWER MOTOR SPEED CONTROL	
	 Press the MAX A/C button blower motor speed override control fully down. Without disconnecting the blower motor speed control C271a from the blower motor speed control, use a fused jumper lead to connect pin 3, circuit 776 (OG/BK) to ground. 	
		Yes GO to R5.
	AL0145-B	No
	 Does the blower motor operation stop or decrease substantially? 	INSTALL a new blower motor speed control. TEST the system for normal operation.
R5	CHECK CIRCUIT 776 (OG/BK) FOR AN OPEN	
	Key in OFF position.Disconnect: RCC Module C228.Key in ON position.	

(Continued)

PINPOINT TEST R: THE BLOWER MOTOR OPERATES CONTINUOUSLY IN HIGH SPEED - EATC (Continued)



PINPOINT TEST S: NO OPERATION IN HIGH BLOWER SETTING - MANUAL CLIMATE CONTROL

	Test Step	Result / Action to Take
S1	CHECK THE BLOWER MOTOR GROUND	
	 Key in OFF position. Disconnect: Blower Motor Resistor C293. Place the blower motor switch in the high position. Measure the resistance between the blower motor resistor C293 pin 2, circuit 261 (OG/BK) and pin 3, circuit 57 (BK). 	
S2	A0013881 • Is the resistance less than 5 ohms?	Yes INSTALL a new blower motor (19805). TEST the system for normal operation. No GO to S2.
32		
	Disconnect: Blower Motor Switch C294a.	
		(Continued)

(Continuea)

PINPOINT TEST S: NO OPERATION IN HIGH BLOWER SETTING — MANUAL CLIMATE CONTROL (Continued)

	Test Step	Result / Action to Take
S2	CHECK CIRCUIT 57 (BK) (Continued)	
	 Measure the resistance between the blower motor switch C294a pin 3, circuit 57 (BK) and ground. 	
		Yes INSTALL a new blower motor switch (18578). TEST the system for normal operation
	A0013882	No REPAIR circuit 57 (BK). TEST the system
	 Is the resistance less than 5 ohms? 	for normal operation.

PINPOINT TEST T: NO OPERATION IN LOWER SPEEDS - MANUAL CLIMATE CONTROL

Test Step	Result / Action to Take
T1 CHECK CIRCUIT 261 (OG/BK)	
 Key in OFF position. Disconnect: Blower Motor C2004. Disconnect: Blower Motor Resistor C293. Measure the resistance between the blower motor C2004, circuit 261 (OG/BK) and the blower motor resistor C293 pin 2, circuit 261 (OG/BK). 	
A0013856 • Is the resistance less than 5 ohms?	Yes GO to T2. No REPAIR circuit 261 (OG/BK). TEST the system for normal operation.
	(Continued)

PINPOINT TEST T: NO OPERATION IN LOWER SPEEDS — MANUAL CLIMATE CONTROL (Continued)

Test Step	Result / Action to Take
T2 CHECK CIRCUIT 57 (BK)	
 Measure the resistance between the blower motor resistor C293 pin 3, circuit 57 (BK) and ground. 	
	Yes INSTALL a new blower motor resistor (19A706). TEST the system for normal operation.
A0013883	
 Is the resistance less than 5 ohms? 	for normal operation.

PINPOINT TEST U: NO OPERATION IN SOME BLOWER SPEEDS — EATC

	Test Step	Result / Action to Take
U1	CHECK THE BLOWER OPERATION	
	 Key in ON position. Press the MAX A/C button and rotate the blower motor speed control to HI. 	Yes The system is functioning correctly.
	 Does the blower speed increase as you rotate the blower motor speed override control toward HI? 	No GO to U2.
U2	CHECK FOR DISCONTINUITIES IN THE CONTROL SIGNAL	
	 Key in OFF position. Without disconnecting the blower motor speed control C271a from the blower motor speed control, measure the voltage between the blower motor speed control C271a pin 3, circuit 776 (OG/BK) and ground. 	
	 Key in ON position. Press the MAX A/C button and adjust the blower motor speed to maximum. Slowly adjust the blower motor speed to minimum while observing the voltmeter. Watch for discontinuities in the voltage as it decreases. The voltage should decrease in steps from 5 volts to a point less than 1 volt. Did the voltage continually decrease without discontinuities? 	Yes INSTALL a new blower motor speed control. TEST the system for normal operation. No GO to U3.
U3	CHECK CIRCUIT 776 (OG/BK) FOR A SHORT TO GROUND	
	Key in OFF position.Disconnect: Blower Motor Speed Control C271a.	

(Continued)

PINPOINT TEST U: NO OPERATION IN SOME BLOWER SPEEDS — EATC (Continued)



Component Tests

A/C Evaporator Discharge Temperature Sensor



Temperature	Resistance
-40°C (-40°F)	832,500-1,017,500 ohms
-20°C (-4°F)	263,100-290,800 ohms
0°C (32°F)	91,050-100,600 ohms
20°C (68°F)	35,500-39,000 ohms
25°C (77°F)	28,500-31,500 ohms
40°C (104°F)	15,300-16,900 ohms
60°C (140°F)	7,170-7,930 ohms
100°C (212°F)	1,975-2,185 ohms
-20°C (248°F)	1,130-1,250 ohms

Heater Core

WARNING: Carbon monoxide is colorless, odorless and dangerous. If it is necessary to operate the engine with the vehicle in a closed area such as a garage, always use an exhaust collector to vent the exhaust gases outside the closed area.

1. **NOTE:** Testing of returned heater cores reveals that a large percentage are good and did not require installation of a new heater core. If a heater core leak is suspected, the heater core must be tested by following the plugged heater core component test before the heater core pressure test. Carry out a system inspection by checking the heater system thoroughly as follows:

Inspect for evidence of coolant leakage at the heater water hose to heater core attachments. A coolant leak in the heater water hose (18472) could follow the heater core tube to the heater core and appear as a leak in the heater core (18476).

2. **NOTE:** Spring-type clamps are installed as original equipment. Installation and over-tightening of non-specification clamps can cause leakage at the heater water hose connection and damage the heater core.

Check the integrity of the heater water hose clamps.

Heater Core—Plugged

WARNING: The heater core inlet hose will become too hot to handle if the system is working correctly.

- 1. Check to see that the engine coolant is at the correct level.
- 2. Start the engine and turn on the heater.
- 3. When the engine coolant reaches operating temperature, feel the heater core outlet hose to see if it is hot.

If it is not hot:

- the heater core may have an air pocket.
- the heater core may be plugged.
- the thermostat (8575) is not working correctly.

Heater Core—Pressure Test

Use the Radiator/Heater Core Pressure Tester to carry out the pressure test.

- NOTE: Due to space limitations, a bench test may be necessary for pressure testing.
 Drain the coolant from the cooling system.
- 2. Disconnect the heater water hoses from the heater core. Refer to Section 412-02.
- 3. Install a short piece of heater water hose, approximately 101 mm (4 inches) long on each heater core tube.
- 4. Fill the heater core and heater water hoses with water and install Plug BT-7422-B and adapter BT-7422-A from the radiator/heater core pressure tester in the heater water hose ends. Secure the heater water hoses, plug and adapter with hose clamps.



- 5. Attach the pump and gauge assembly from the radiator/heater core pressure tester to the adapter.
- 6. Close the bleed valve at the base of the gauge. Pump 138 kPa (20 psi) of air pressure into the heater core.
- 7. Observe the pressure gauge for a minimum of three minutes.
- 8. If the pressure drops, check the heater water hose connections to the core tubes for leaks. If the heater water hoses do not leak, remove the heater core from the vehicle and carry out the bench test.

Heater Core—Bench Test

- 1. Remove the heater core from the vehicle. Refer to Section 412-02.
- 2. Drain all of the coolant from the heater core.

- 3. Connect the 101 mm (4 inch) test heater water hoses with plug and adapter to the core tubes. Then connect the radiator/heater core pressure tester to the adapter.
- 4. Apply 138 kPa (20 psi) of air pressure to the heater core. Submerge the heater core in water.
- 5. If a leak is observed, install a new heater core.



A/C Evaporator/Condenser Core—On-Vehicle Leak Test

- 1. Discharge and recover the refrigerant. Refer to Air Conditioning (A/C) System Recovery, Evacuation and Charging in this section.
- 2. AUTION: DO NOT leak test an evaporator core with the suction accumulator attached to the core tubes.

Disconnect the suspect evaporator core (19860) or condenser core (19712) from the A/C system. Refer to Section 412-03.

- 3. Clean the spring lock couplings. Refer to Spring Lock Coupling in this section.
- 4. Connect the appropriate test fittings from the R-12/R-134a Air Conditioning Test Fitting Set to the evaporator or condenser tube connections.
- 5. **NOTE:** The automatic shut-off valves on some gauge set hoses do not open when connected to the test fittings. If available, use hoses without shut-off valves. If hoses with shut-off valves are used, make sure the valve opens when attached to the test fittings or install an adapter which will activate the valve. The test is not valid if the shut-off valve does not open.

Connect the red and blue hoses from the R-134a Manifold Gauge Set to the test fittings on the evaporator core or condenser core. Connect the yellow hose to a known good vacuum pump.

- 6. Open both gauge set valves and start the vacuum pump. Allow the vacuum pump to operate for a minimum of 45 minutes after the gauge set low pressure gauge indicates 101 kPa (30 inches-Hg). The 45 minute evacuation is necessary to remove any refrigerant from oil left in the evaporator core or condenser core. If the refrigerant is not completely removed from the oil, outgassing will degrade the vacuum and appear as a refrigerant leak.
- 7. If the low pressure gauge reading will not drop to 101 kPa (30 inches-Hg) when the valves on the gauge and manifold set are open and the vacuum pump is operating, close the gauge set valves and observe the low pressure gauge. If the pressure rises rapidly to zero, a large leak is indicated. Recheck the test fitting connections and gauge set connections before installing a new evaporator core or condenser core.
- 8. After evacuating for 45 minutes, close the gauge set valves and stop the vacuum pump. Observe the low pressure gauge; it should remain at the 101 kPa (30 inches-Hg) mark.
 - If the low pressure gauge reading rises 34 kPa or more (10 inches-Hg or more) of vacuum from the 101 kPa (30 inches-Hg) position in 10 minutes, a leak is indicated.
 - If a very small leak is suspected, wait 30 minutes and observe the vacuum gauge.
 - If a small amount of vacuum is lost, operate the vacuum pump with gauge valves open for an additional 30 minutes to remove any remaining refrigerant from the oil in the evaporator core or condenser core. Then recheck for loss of vacuum.
 - If a very small leak is suspected, allow the system to set overnight with vacuum applied and check for vacuum loss.
- 9. If the evaporator core or condenser core does leak, as verified by the above procedure, install a new evaporator core or condenser core. Refer to Section 412-03.

A/C Compressor—External Leak Test

1. Install the A/C pressure test adapter on the rear head of the A/C compressor (19703) using the existing manifold retaining bolt.

- Connect the high and low pressure lines of a manifold gauge set or a refrigerant recovery/recycling station such as the R-134a A/C Refrigerant Center to the corresponding fittings on the A/C pressure test adapter.
- 3. Attach the center hose of the R-134a Manifold Gauge Set to a refrigerant container standing in an upright position.
- 4. Hand-rotate the compressor shaft 10 complete revolutions to distribute the oil inside the A/C compressor.
- 5. Open the low pressure gauge valve, the high pressure gauge valve and the valve on the refrigerant container to allow the refrigerant vapor to flow into the A/C compressor.
- 6. Using the Refrigerant Leak Detector, check for leaks at the compressor shaft seal and the compressor center seal.
- 7. If a shaft seal leak is found, install a new shaft seal. Refer to Section 412-03. If an external leak is found at the center joint of the A/C compressor, install a new A/C compressor.
- 8. When the leak test is complete, recover the refrigerant from the compressor.